



Oldcastle BuildingEnvelope®

***TCR-250 WINDOW WALL
INSTALLATION AND GLAZING MANUAL***

*Note: Installation and Glazing Manuals are product specific. **FOR REVIEW ONLY!***

TCR-250 WINDOW WALL INSTALLATION MANUAL

TABLE OF CONTENTS

	Page
General Information	
Product Use	1
Protection and Storage	2
Check Material	2
Field Conditions	2
Cleaning Materials	2
Expansion Joints	3
Suggestions for Improving Thermal Performance	3
Typical Frame Configurations	4
Frame Fabrication	
Measuring Opening	5
Cutting Material	5
Anchor at Incidental Water Application	6
Head & Sill Fabrication	7
Vertical Mullion Fabrication	8
Horizontal & Weep Hole Fabrication	9
Frame Assembly	
Vertical & Horizontal Attachment and Sealing	10
End Dam Attachment and Sealing	10
Frame Installation	
Head & Sill Anchor Installation	11
Zone Plug Installation	11
Perimeter Sealant Application	12
SSG Bridge Installation	12
Glazing	
Glass Size Calculation	12
Gasket Installation	12
Setting Block Location	12
Setting the Glass	12
Glass Stop Installation	12
Glazing Frames with SSG Verticals	13
Side Block Installation	13
Frame Splicing	
Head & Sill Splicing	14
Reglazing	
Modification for Reglazing	15
Reglazing	16
CORNER ASSEMBLY	
90 Outside Corner Assmembly (6" System)	17-18
90 Outside Corner Assmembly (4-1/2" System)	19-20
PARTS LIST	
4-1/2" and 6" Systems Parts List	21-24

Quick Reference Guide

1. Cut lengths taken from D.L.O. dimensions are measured from the inside of the mullions. Face members are slightly more narrow to provide a good joint seal. SEE PAGE 5
2. End reaction limitations: 4-1/2" System - 600 lbs without reinforcing sleeve - 875 lbs with sleeve. SEE PAGE 9
3. Outside 90 Corner options: 4-1/2" System - Head & Sill Run Thru- 6" System -Corner Mullions run thru.

TCR-250 WINDOW WALL INSTALLATION MANUAL

GENERAL INFORMATION

PRODUCT USE

The TCR-250 window wall system is intended for installation by glazing professionals with appropriate experience. Subcontractors without experience should employ a qualified person to provide field instruction and project management.

Oldcastle BuildingEnvelope® does not control the application or selection of its product configurations, sealant or glazing material and assumes no responsibility thereof. It is the responsibility of the owner, architect and installer to make these selections in strict compliance with applicable laws and building codes.

Consult sealant manufacturer for review and recommendation of sealant application. Follow sealant manufacturer's recommendations and literature for proper installation.

The air and water performance of the **TCR-250** window wall system is directly related to the completeness and integrity of the installation process both the seal installed at the shear blocks and mullion joinery and the glazing gasket installed at the interior side of the glass. To insure top performance for this system, particular attention should be given the following procedures:

1. Surfaces to be sealed should be cleaned with isopropyl alcohol or solvent and dried as recommended by sealant manufacturer to remove all dirt and cutting oils. Sealant at shear blocks should be a minimum 3/16" diameter nominal placed completely around the top, face and bottom of the shear block without gaps in the sealant. Exposed surfaces should be cleaned after installing the horizontal. Inspect joint for complete sealant contact, especially where the horizontal meets the face of the vertical member. Repair joint as required.
2. The interior glazing gasket should be installed so as to avoid stretching, buckles or tears. Corners must be cut square, sealed and butted together. To avoid damage to gasket and corner joints during glazing, glass should be level and straight during installation.

Variations on the details shown are inevitable and are not the responsibility of Oldcastle BuildingEnvelope® when drawn by others. Oldcastle BuildingEnvelope® strongly encourages its customers to use its Engineering department for calculations and shop drawings.

For Structural Silicone Glazing applications, the stress on the silicone should not exceed 20 PSI. Consult sealant manufacturer for specific applications to ensure proper loading on silicone joint. Alternate spacer gaskets are available to accommodate larger sealant contact widths. Consult your nearest Oldcastle BuildingEnvelope® facility for assistance.

Consult glass manufacturer for correct setting block location and length for glass sizes in excess of 40 sq.ft.

TCR-250 WINDOW WALL INSTALLATION MANUAL

GENERAL INFORMATION

PROTECTION AND STORAGE

Handle all material carefully. Do not drop from the truck. Stack with adequate separation so the material will not rub together. Store material off the ground, protecting against the elements and other construction hazards by using a well ventilated covering. Remove material from package if wet or located in a damp area. For further guidelines consult AAMA publication "Care and Handling of Architectural Aluminum From Shop to Site."

CHECK MATERIAL

Check glass dimensions for overall size as well as thickness. Oldcastle BuildingEnvelope® cannot be held responsible for gaskets that are not water tight due to extreme glass tolerances. The TCR-250 window wall system is designed to accommodate glass or panels measuring 1" in thickness. (+/- 1/32")

Check all material upon arrival at job site for quality and to determine any shipping damage.

Using the contract documents, completely check the surrounding conditions that will receive your materials. Notify the general contractor by letter of any discrepancies before proceeding with the work. Failure to do so constitutes acceptance of work by other trades.

Check shop drawings, installation instructions, architectural drawings and shipping lists to become familiar with the project. The shop drawings take precedence and include specific details for the project. The installation instructions are of a general nature and cover the most common conditions. Due to varying job conditions all sealant used must be approved by the sealant manufacturer to insure it will perform per the conditions shown on the instructions and shop drawings. The sealant must be compatible with all surfaces in which adhesion is required, including other sealant surfaces. Use primers where directed by sealant manufacturer. Properly store sealant at the recommended temperatures and check sealant for remainder of shelf life before using.

FIELD CONDITIONS

All material to be installed must be plumb, level and true. Aluminum to be placed in direct contact with masonry or incompatible material should be isolated with a heavy coat of zinc chromate, bituminous paint or non-metallic material.

After sealant is set and a representative amount of the wall has been glazed (250 square feet or more), run a water hose test in accordance with AAMA 501.2 specifications to check installation. On large projects the hose test should be repeated during the glazing operation.

CLEANING MATERIALS

Cement, plaster terrazzo, alkaline and acid based materials used to clean masonry are very harmful to finishes. Any residue should be removed with water and mild soap immediately or permanent staining will occur. A spot test is recommended before any cleaning agent is used. Refer to the **Architectural Finish Guide** in the Detail Catalog.

TCR-250 WINDOW WALL INSTALLATION MANUAL

GENERAL INFORMATION

EXPANSION JOINTS

Expansion joints and perimeter joints shown in these instructions and in the shop drawings are shown at nominal size. Actual dimensions may vary due to perimeter conditions and/or differences in metal temperature between the time of fabrication and the time of installation. For example, a 12 foot unrestrained length of aluminum can expand or contract 3/32" over a temperature change of 50° F. Any movement potential should be accounted for at the time of the installation.

SUGGESTIONS FOR IMPROVING SYSTEM THERMAL PERFORMANCE

To maintain or improve your wall installation the following items should be considered.

- A. Blinds or drapes prevent warm air from adequately flowing over the window surface.
- B. Warm air ventilators too far from the window will not adequately wash the window with air to prevent condensation.
- C. In extreme conditions the fan of the heating system should not cycle on and off, but should run continuously.
- D. Some heating systems have a water injection feature that can raise humidity levels. The higher the humidity levels the more likely condensation or frost will form. Raising the temperature and reducing humidity will usually solve the problem.
- E. On rare occasions an extremely cold storm may cause frost to appear on the glass framing. A space heater and electric fan blowing along the plane of the window wall can reduce or eliminate this temporary condition.

TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME CONFIGURATIONS

The frames shown below are representative of typical frame configurations that are covered in these instructions. Contact your local Oldcastle BuildingEnvelope[®] facility for custom configurations involving non-standard installation methods.




Figure 1
Standard Punched Opening




Figure 2
Extended Frame (Width > 24'-0")

TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME FABRICATION

NOTE : Structural silicone glazed vertical mullion is referred to as “SSG mullion”

1.1 Measure ROUGH OPENING to determine FRAME WIDTH and FRAME HEIGHT dimensions. Allow 1/2” minimum clearance for shimming and caulking around perimeter of frame.

1.2 Cut material to size. **SEE FIGURE 3 PAGE 6** for guide.

Frame Members

Sill Anchor.....	FRAME WIDTH minus 1/2" (splice if greater than 24'-0")
Head and Sill (<24'-0").....	FRAME WIDTH
Head and Sill (>24'-0").....	Refer to FRAME SPLICING, page 14
Head and Sill Face Covers.....	See 'Head and Sill' for cut length
Verticals and Jambs.....	FRAME HEIGHT minus 3 13/16" (see FIG. 5, p.5 for notching)
Intermediate Horizontals.....	Daylight Opening (D.L.O.) minus 1/16"
Glass Stops.....	D.L.O. minus 1/32"
Horizontal Face Covers.....	D.L.O.
Horizontal Face Covers @ SSG.....	Bay Width (see FIGURE 3)

***NOTE: D.L.O. IS MEASURED AT INTERIOR OF MULLIONS.**

Accessories

Glazing gaskets

Verticals.....	D.L.O. plus 1" plus allowance*
Horizontals.....	D.L.O. plus allowance* (run between vertical gaskets)
Silicone spacer gaskets.....	D.L.O. plus 1" plus allowance*

*Glazing gaskets should be cut 1/4" longer per foot. Set aside and lay flat until ready to glaze.

1.3 Fabricate head and sill members for vertical and jamb attachment. **SEE FIGURE 4, page 7.**

1.4 Fabricate vertical mullions for intermediate horizontal members. Notch tops of all verticals and jambs for head member. **SEE FIGURE 5 , page 8.**

1.5 Fabricate intermediate horizontals for shear block fasteners. **SEE FIGURE 6, page 9.**

1.6 Drill 1/4" diameter weep holes in horizontal and sill members at 1/4 points. Install HP-1004 baffles as required, securing with a drop of silicone if needed. If frame is to accommodate incidental water, drill (1) 1/4" diameter weep hole at centerline of lite in head member and install a baffle. **SEE FIGURE 7, page 9.**

1.7 Drill one 1/4" diameter weep hole at the bottom center of each light of glass at head, sill and horizontal face covers. **NOTE: For SSG applications, there will be multiple holes per face cover.**

TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME FABRICATION





FIGURE 3
Material Fabrication Guide

- 1.8 If "C" shaped head anchor is used, drill access holes in head member for anchor. See approved shop drawings for location and quantity. Note: Head anchors are pre-loaded into frame and secured to the building condition after frame is set in place. **"C" SHAPED HEAD ANCHOR SHOULD NOT BE USED WHEN USING INCIDENTAL WATER HEAD.** Consult your nearest Oldcastle BuildingEnvelope[®] facility for anchoring options at these conditions. **SEE DETAIL BELOW.**



Anchor at Incidental Water Application

TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME FABRICATION




Figure 4
Head & Sill Fabrication

TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME FABRICATION





Figure 5
Vertical Mullion Fabrication

TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME FABRICATION



FRAME ASSEMBLY

Prior to applying sealant to any frame member, the aluminum must be cleaned. Consult sealant manufacturer for cleaning recommendations.

- 2.1 If frame has horizontal mullions, attach shear blocks to jambs and verticals with (2) FS-9, 1/4-14 x 1 1/2" Hex Head screws.

If frame is to accommodate incidental water at the head, slide strap anchors into the head member prior to setting the frame in the opening.

- 2.2 If end reactions exceed 700 lbs. (4 1/2" and 6" systems) a reinforcing sleeve must be inserted in the head & sill member at each vertical location. Attach with vertical assembly screws. **SEE FIGURE 9. Note: Max end reaction at head & sill with reinforcing sleeves is 900 lbs. (4 1/2" and 6" systems).**

TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME ASSEMBLY

- 2.3 Attach PVC end dams to each end of head and sill member with (2) FS-320 #10 U-drive. Bed end dams in sealant and seal as shown on **FIGURE 8**. Cap seal FS-320 drive screws.
- 2.4 Apply face covers to head and sill members. Install by setting long leg into head or sill snap then rotate towards short cap leg to snap in place. **See FIGURE 9**.
- 2.5 Seal top & bottom of verticals prior to attaching to head and sill. At jambs, seal end dam area that will contact the jambs. Attach to head & sill with (2) FS-9 1/4-14 x 1 1/2" HH screws. **DO NOT OVER TORQUE SCREWS**. Seal screws at head members. **SEE FIGURE 9**.
- 2.6 NOTE: Horizontals can be attached before or after frame is installed. If installed prior and shipped to jobsite, care must be taken not to disturb seals in transit. Prior to attaching intermediate horizontals, apply sealant to face of shear blocks. Roll the horizontal over the shear blocks & attach with (1) FS-55 #10 x 1/2" Phillips RH screw. Seal ends of horizontal. **SEE FIGURE 10**.





Figure 8
End Dam Attachment







Figure 10
Horizontal Installation

Figure 9
Vertical Attachment & Sealing

TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME INSTALLATION

Unless noted otherwise, these instructions describe installation of frames using the standard "C" shaped head anchor.

- 3.1 Shim continuous sill anchor off floor. Anchor must be level. **SEE FIGURE 11** for shim placement. Ends of sill anchor should be equal distance from wall on either side of opening. Refer to approved shop drawings for anchor size and placement. NOTE: Front of sill anchor is $2\frac{3}{8}$ " behind rear edge of wall at $4\frac{1}{2}$ " system; $3\frac{7}{8}$ " at 6" system.

- 3.2 Prior to setting frame, tape head anchor pieces above access hole locations in head. Place frame onto sill anchor & tilt into opening plumb, square & level. Check caulk joints to insure uniformity. Anchor head through access holes per approved shop drawings. NOTE: FOR OPTIMAL PERFORMANCE OF HEAD ANCHOR, DIE LINES MUST BE VISIBLE ON THE ANCHOR AT THE TOP OF THE FRAME. **SEE FIGURE 12.** Seal over access hole on the inside.

If horizontals & zone plugs were pre-installed in the shop, check these seals before proceeding to insure they are intact. Repair as necessary. Skip to step 3.4.

- 3.3 Install & seal zone plugs at captured verticals as shown in **FIGURE 13**. Tool sealant into space between zone plug & vertical & horizontal. Where there are SSG verticals, install & seal bridges. **SEE FIGURE 14 PAGE 12.**

- 3.4 Seal perimeter of frame. Care must be taken to marry seals at the corners of the frame. Interior seals are not required for system performance, but may be necessary for cosmetic purposes. **SEE FIGURE 15 PAGE 12.**




Figure 11
Shim Placement at Sill Anchor




Figure 12
Head Anchor Position

Apply sealant to end of horizontal prior to installing zone plug

Seal zone plug to vertical & horizontal
NOTE: Thoroughly seal mullion tongue





Figure 13
Zone Plug Installation



TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME INSTALLATION




Figure 14
SSG Bridge Installation




Figure 15
Perimeter Seal

GLAZING

Start glazing the frame at the bottom and work up.

GLASS SIZE CALCULATION:

D.L.O. + 1" for WIDTH and HEIGHT at CAPTURED MULLIONS (including corners)

D.L.O. + 2" for WIDTH at SSG VERTICALS


- 4.1 **Note:** To avoid silicone curing before glass is set in place, and contamination from job-site debris, glazing prep must be done as each opening is glazed. Do not pre-seal the gaskets in the entire frame; install and seal gaskets as you are ready to set glass in each opening. Install exterior gaskets. Glazing gaskets at verticals run through; horizontal gaskets butt into vertical gaskets. Gaskets at head and sill members run through. Crowd the gaskets into corners, cutting the horizontal gasket at an angle to match bevel on adjoining gaskets. Seal joint between the corners of the gaskets just prior to glazing.

NOTE: Sealant is not required at the horizontal gasket abutting an SSG mullion. This gap will be sealed during structural silicone application.

- 4.2 Position setting blocks at correct location (two per lite). Refer to approved shop drawings or dead load charts. Lubricating the top of the setting block will help insure proper setting of glass. **Note:** Consult glass manufacturer for correct setting block location and length for glass sizes exceeding 40 sq.ft.
- 4.3 Set glass in opening. Ensure that glass bite is equal on all sides. For frames with SSG verticals, glass can be set from the interior. **SEE FIGURE 16, page 13** for glazing sequence. **CAUTION:** Be certain that glass is placed firmly against exterior gasket to ensure a proper seal and to avoid binding of the glass on the setting block.
- 4.4 Install glass stops and run interior wedge gasket, crowding into the corners. Seal corners of wedge gasket at the bottom of each lite after all gaskets have been installed on the lite.


TCR-250 WINDOW WALL INSTALLATION MANUAL

GLAZING



4.5 Install side blocks in vertical mullions as required. **SEE FIGURE 17.** Consult glass manufacturer for preferred location in seismic areas. **Note: Side blocks are not required at SSG mullions.**

4.6 Repeat steps 4.1 through 4.5 until all glass is set, working row by row up the elevation.



TCR-250 WINDOW WALL INSTALLATION MANUAL

FRAME SPLICING

When the FRAME WIDTH exceeds 24'-0", the head and sill members must be spliced. Locate splice joints at or near mid-lite. Splice sill anchors 12" from the frame splice. Head and sill members should be cut to allow for a $\frac{1}{2}$ " splice joint between each frame section. Sill anchors can be butted together. Locate an anchor bolt 3" from each side of the sill anchor joint. Locate a head anchor at the head splice joint.

A.1 Prior to setting frames in place, apply a non-hardening, non-skinning sealant to both sides of the splice joint at the head and sill members.

A.2 Place splice sleeves in head and sill of first frame section. Pin in place with FS-114 #8 x $\frac{3}{8}$ " Phillips pan head screw (seal head). **SEE FIGURE 18.** Slide the next frame section over the splice sleeves to achieve a $\frac{1}{2}$ " joint.




Figure 18
Head & Sill Member Splicing

A.3 Offset head and sill face cover splice joints 3" from main member splices. Set joint at face covers at $\frac{1}{2}$ " and seal as necessary.

A.4 Follow instructions for shimming and anchoring the frame.

A.5 Seal over gap at splice joint.

TCR-250 WINDOW WALL INSTALLATION MANUAL

REGLAZING FROM EXTERIOR

NOTE: These instructions cover the replacement of glass below an intermediate horizontal. The same procedures can be used if a lite must be reglazed at a head member.

B.1 Remove face cover from member above affected lite (i.e., horizontal or head).

B.2 Remove lite of glass and all glazing gaskets from opening to be reglazed.

B.3 The bottom glazing leg of the horizontal member above removed lite must be cut away. Carefully cut along the V-groove at the face of leg. **SEE FIGURE 19.**




Figure 19
Reglazing Procedure

B.4 Clean pocket of debris, dirt and oils. Apply reglazing sponge gasket with pre-applied adhesive backing to interior of pocket. Crowd gasket into corners to prevent gaps and seal gasket intersections thoroughly.

B.5 Glaze new lite, ensuring that setting chair and setting block are properly located. Care must be taken during glazing to avoid disturbing or damaging interior sponge gaskets. Hold glass in place temporarily with short pieces of wedge gasket at sides of lite.

B.6 Run continuous bead of sealant along the face of the horizontal, then screw apply the reglaze leg with FS-19 #10 x 5/8" HWH Self Drilling Fastener at 12" O.C. and 1-1/2" from ends. Cap seal fasteners. **SEE FIGURE 20.**

B.7 Install wedge gasket around exterior of lite and replace horizontal face covers to complete reglazing procedure.

TCR-250 WINDOW WALL INSTALLATION MANUAL

REGLAZING FROM THE EXTERIOR





Figure 20
Exterior Reglazing

TCR-250 WINDOW WALL INSTALLATION MANUAL

OUTSIDE 90° CORNER ASSEMBLY for 6" SYSTEM

FIGURE 21 shows the basic layout of the standard one-piece corner mullion assemblies for 6" system depths. These details are for general reference and do not necessarily reflect all conditions. For specific assembly, sealing and anchoring notes, refer to approved shop drawings.



NOTE:

TCR-282-01 (R) -TCR-282-02 (L) at Sill

TCR-283-01 (R) -TCR-283-02 (L) at Standard Head

TCR-284-01 (R) -TCR-284-02 (L) at Incidental Water Head

TCR-285-01 (R) -TCR-285-02 (L) at Horizontal

TCR-250 WINDOW WALL INSTALLATION MANUAL

OUTSIDE 90° CORNER ASSEMBLY for 6" SYSTEM (CONT.)








Figure 21 (cont.)

OS 90 Corner Assembly
6" Deep System

OS 90 Corner Assembly Guide
(See details below for fabrication notes)



TCR-250 WINDOW WALL INSTALLATION MANUAL

OUTSIDE 90° CORNER ASSEMBLY for 4 1/2" SYSTEM

FIGURE 22 shows the basic layout of the standard one-piece corner mullion assemblies for both the 4 1/2" and 6" system depths. These details are for general reference and do not necessarily reflect all conditions. For specific assembly, sealing and anchoring notes, refer to approved shop drawings.





Figure 22
OS 90 Corner Assembly
4 1/2" Deep System


TCR-250 WINDOW WALL INSTALLATION MANUAL

OUTSIDE 90° CORNER ASSEMBLY for 4 1/2" SYSTEM (CONT.)


Figure 22 (cont.)
OS 90 Corner Assembly
4 1/2" Deep System



OS 90 Corner Assembly Guide
(See details below for head/sill splices)



Head Splice Detail



Sill Splice Detail

NOTE:












Splice sleeves sold in packages.
TCR-493 for head member and
TCR-494 for sill member

TCR-250 WINDOW WALL INSTALLATION MANUAL













PARTS LIST

(parts not shown to scale)

4-1/2" System Extrusions

	Sill Anchor
TCR-102	
	90° Outside Corner Mullion
TCR-250	
	Glass Stop at Intermediate Horizontal
TCR-413	
	Jamb Mullion
TCR-453	
	SSG Mullion
TCR-454	
	Head
TCR-471	
	Intermediate Horizontal
TCR-472	
	Glass Stop at Head
TCR-473	
	Typical Vertical Mullion
TCR-480	
	Optional Head for Incidental Water
TCR-481	
	Sill
TCR-482	

6" System Extrusions








	Sill Anchor
TCR-103	
	90° Outside Corner Mullion
TCR-350	
	90° Outside Corner Pressure Plate
TCR-351	
	Glass Stop at Intermediate Horizontal
TCR-613	
	Jamb Mullion
TCR-653	
	SSG Mullion
TCR-654	
	Head
TCR-671	
	Intermediate Horizontal
TCR-672	
	Glass Stop at Head
TCR-673	
	Typical Vertical Mullion
TCR-680	
	Optional Head for Incidental Water
TCR-681	
	Sill
TCR-682	

TCR-250 WINDOW WALL INSTALLATION MANUAL





PARTS LIST

(parts not shown to scale)










Common Extrusions

	Horizontal Face Cap
TCR-112	
	90° Outside Corner Face Cap
TCR-113	
	Head & Sill Face Cap
TCR-121	
	Reglaze Leg at Horizontal
TCR-132	
	Reglaze Leg at Head
TCR-133	
	Thermal Door Stop
DS-117	
	Typical Door Stop
FG-2145	



Parts and Accessories - 4-1/2" System

	Head Anchor for TCR-481
TCR100-01	
	Head Reinforcing Sleeve for TCR-471
TCR106-01	
	Head Reinforcing Sleeve for TCR-481
TCR107-01	
	Head Anchor for TCR-471
TCR200-01	

Parts and Accessories - 4-1/2" System (cont.)

	Sill Reinforcing Sleeve for TCR-482
TCR201-01	
	Typical Shear Block
TCR280-01	
	PVC End Dam for Head & Sill
TCR-312	
	Splice Package for TCR-471 Head
TCR-293, TCR-295, TCR-197, TCR-490	
	Splice Package for TCR-481 Head
TCR-293, TCR-296, TCR-297, TCR-298, TCR-197, TCR-491	
	Splice Package for TCR-482 Sill
TCR-182, TCR-183, TCR-195, TCR-492	
	Clip Package for 90° Outside Corner at Head
TCR-182, TCR-183, TCR-493	
	Clip Package for 90° Outside Corner at Sill
TCR-184, TCR-494	
	Drill Jig for 4-1/2" System
DJ-109	

Parts and Accessories - 6" System













	Sill Reinforcing Sleeve for TCR-682
TCR114-01	
	Head Anchor for TCR-681
TCR160-01	








TCR-250 WINDOW WALL INSTALLATION MANUAL

PARTS LIST





(parts not shown to scale)

Parts and Accessories - 6" System (cont.)

	Head Reinforcing Sleeve for TCR-671
TCR206-01	
	Head Reinforcing Sleeve for TCR-681
TCR207-01	
	Head Anchor for TCR-671
TCR210-01	
	Typical Shear Block
TCR281-01	
	Sill Shear Block at 90° Outside Corner - Left Hand
TCR282-01	
	Sill Shear Block at 90° Outside Corner - Right Hand
TCR282-02	
	Head Shear Block at 90° Outside Corner - Left Hand
TCR283-01	
	Head Shear Block at 90° Outside Corner - Right Hand
TCR283-02	
	Incidental Water Head Shear Block at 90° Outside Corner - Left Hand
TCR284-01	
	Incidental Water Head Shear Block at 90° Outside Corner - Right Hand
TCR284-02	
	Intermediate Horizontal Shear Block at 90° Outside Corner - Left Hand
TCR285-01	
	Intermediate Horizontal Shear Block at 90° Outside Corner - Right Hand
TCR285-02	

	PVC End Dam for Head & Sill
TCR-313	
	90° Outside Corner Mullion End Cap
TCR-314	
	90° Outside Corner Foam Zone Plug
TCR-364	
	Splice Package for TCR-671 Head
TCR-293 TCR-299 TCR-197 TCR-690	
	Splice Package for TCR-681 Head
TCR-293 TCR-302 TCR-287 TCR-197 TCR-691	
	Splice Package for TCR-682 Sill
TCR-294 TCR-196 TCR-692	
	Drill Jig for 6" System
DJ-111	

Common Parts & Accessories













	Weep Baffle at Head & Sill
HP-1004	
	Temporary Glazing Retainer for SSG Verticals
SPW-PP-3	
	Setting Chair
TCR120-01	
	SSG Bridge
TCR-300	








TCR-250 WINDOW WALL INSTALLATION MANUAL

PARTS LIST

(parts not shown to scale)

Common Parts & Accessories (cont.)

 WW-364	Zone Plug - Deep Pocket
 WW-365	Zone Plug - Shallow Pocket
 GP-100	EPDM Sponge Gasket w/ PSA (for reglaze)
 GP-101	Setting Block
 GP-102	SSG Spacer
 GP-103	Typical Fixed Gasket
 GP-104	Optional EPDM Sponge Gasket
 GP-113	Typical Wedge Gasket
 GP-114	Side Block for Shallow Pocket
 GP115	'W' Side Block for Deep Pocket
 FS-6	#10 x 3/4" PPH B Pt., for horizontal attachment of shear blocks.
 FS-7	#10 x 3/4" PFH B Pt., for horizontal attachment of shear blocks

 FS-8	#14 x 1" HH B Pt., Frame Assembly Fastener
 FS-9	#14 x 1-1/2" HH Pt., Assembly Fastener at Reinforcement Sleeves
 FS-19	#10 x 5/8" HWH TEK, Attachment of Reglaze Legs & Head/Sill Splices
 FS-55	#10 x 1/2" PPH AB Pt., for horizontal attachment of shear blocks
 FS-114	#8 x 3/8" PPH A Pt., Attachment of SSG Bridge
 FS-320	M4 x 16mm Headed Helical Pin, for attachment of end dams
 FS-325	#12-24 x 1-11/32" HWH Drill Flex, for attachment 6" System OS90 Pressure Plate